



Connect these 2 wires to a 1/4" mono plug then insert the 1/4" plug into the rear HG-10/10B or VF-1 rear panel VFO KEY socket

The above Receive, Antenna, and Transmitter connections are made to 3 SO-239 sockets mounted on a metal enclosure