





# Heathkit

## DX40 and DX60 Transmit / Receive

### 3PDT change over relay



120VAC  
Relay Coil

The relay is shown in "Receive" (relay is not energized). Note the VFO KEY JACK is not shorted to ground hence no RF output from the HG10 VFO in receive